

Insta-Test
ANALYTIC

SANITIZED WATER
TEST STRIPS

QAC

50-400 ppm

100 Strips

LaMotte



QAC ppm



50

100

200

400

1. Dip strip & remove.
 2. Shake off excess water.
 3. Wait 5 seconds.
 4. Compare.
- Wait 45 seconds if testing Hyamine 1662
 - Keep wet fingers out of the bottle
 - Cap bottle tightly after opening
 - Store in a cool, dry place

Code 2951

LaMotte Company

802 Washington Avenue
Chestertown, MD 21620 USA
lamotte.com



6

37395 03597

5

Made in
USA