

PHOSPHATE KIT

Code 4401-02 | Octa-Slide 2, 10-80 ppm



QUANTITY	CONTENTS	CODE
30 mL	*VM Phosphate Reagent	*4410-G
30 mL	Pipet, 1.0 mL, plastic	0354
4	Test Tubes, 5 mL, plastic, w/caps	0106
1	Octa-Slide 2 Viewer	1101
1	Phosphate Octa-Slide 2 Bar, 10-80 ppm	4412-01

To order individual reagents or test kit components, use the specified code number.

*Reagent is a potential health hazard. **READ SDS:** lamotte.com
Emergency information:
Chem-Tel USA 1-800-255-3924
Int'l, call collect, 813-248-0585



Warning! This set contains chemicals that may be harmful if misused. Read cautions on individual containers carefully.
Not to be used by children except under adult supervision.

HOW TO USE THE OCTA-SLIDE 2 VIEWER

PROCEDURE

1.

Insert Phosphate Octa-Slide 2 Bar [4412-01] into the Octa-Slide 2 Viewer [1101].

2.

Fill a test tube [0106] to the 5 mL line with sample water.

3.

Use the 1.0 mL pipet [0354] to add 1.0 mL of *VM Phosphate Reagent [4410].

4.

Cap and mix.

5.

Wait 5 minutes.

6.

Insert test tube into Octa-Slide 2 Viewer [1101].

7.

Match sample color to a color standard. Record as ppm Phosphate.